



# **Technical Note Updating the LoadMaster Software**

**8 January 2024**

# Copyright

---

Visit the following page online to see Progress Software Corporation's current Product Documentation Copyright Notice/Trademark Legend: [Product Documentation Copyright Notice & Trademarks | Progress](#)

# Table of Contents

**Chapter 1: Introduction. . . . . 4**

Document Purpose. . . . . 4

Intended Audience. . . . . 5

Prerequisites. . . . . 5

**Chapter 2: Updating the LoadMaster Software. . . . . 6**

Download the Software Update. . . . . 6

Back Up the LoadMaster Configuration. . . . . 7

    Back Up the System. . . . . 7

    Back Up the Certificates. . . . . 8

    Back Up Cipher Sets In Use. . . . . 8

Updating the Software. . . . . 9

**Chapter 3: Restoring the Software. . . . . 11**

Restore the Software – No Changes Made. . . . . 11

Restore the Software – Changes Made. . . . . 12

Restoring Certificates and Private Keys. . . . . 13

**Chapter 4: References. . . . . 14**

---

# Introduction

---

## Introduction

New versions of the LoadMaster software are released on a quarterly basis. Each new software release comes with a host of new features, feature enhancements and bug fixes. To find out what is included in a LoadMaster software version, please refer to the [LoadMaster Release Notes](#).

Customers can download the latest software from the Progress Kemp website. The firmware can then be installed on the LoadMaster.

### Related Links

- [Document Purpose](#)
- [Intended Audience](#)
- [Prerequisites](#)

## Document Purpose

### Document Purpose

This document describes the steps to upgrade the LoadMaster software. We recommend performing a full backup of the system before updating the software.

# Intended Audience

## Intended Audience

This document is intended to be read by anyone interested in finding out how to upgrade the LoadMaster firmware.

# Prerequisites

## Prerequisites

If you plan on updating from a pre-LTS firmware version to a post-LTS firmware version, you must first upgrade to LTS. This is because the kernel was upgraded in the LTS version. You can follow the steps in this document to do this, but ensure to update to the LTS version before updating to a later version.

Before upgrading the LoadMaster firmware version, it is also a good idea to back up:

- The LoadMaster base configuration
- The LoadMaster's certificates
- Any cipher sets that are currently in use

Refer to the [Back Up the LoadMaster](#) section for instructions on how to do this.

---

## Updating the LoadMaster Software

---

### Updating the LoadMaster Software

Follow the steps in the sub-sections below to back up and update the LoadMaster software.

---

**Note:** You will experience issues accessing the LoadMaster if all of the below conditions are met:

- You update the LoadMaster firmware from a version below LTS to 7.2.XX
- Any time after updating the firmware, you change the password to access the LoadMaster
- After changing the LoadMaster password, you downgrade to version 7.1.XX

This is because the hashing algorithm changed in version 7.2.36. LoadMasters with firmware version 7.2.36 and above can read old passwords, but LoadMasters with firmware version 7.1.XX cannot read new passwords.

---

#### Related Links

- [Download the Software Update](#)
- [Back Up the LoadMaster Configuration](#)
- [Updating the Software](#)

## Download the Software Update

### Download the Software Update

To download the latest version of the LoadMaster software, follow the steps below:

1. Go to <https://support.kemptechnologies.com>.
2. Log in to the site by clicking the **Sign in** link at the top and entering your Kemp ID details.

For instructions on how to register for a Kemp ID, refer to the [Licensing, Feature Description](#).

3. Click Downloads.
4. Click the relevant download link, depending on your type of LoadMaster.
5. Continue following the relevant links to download the software.

## Back Up the LoadMaster Configuration

### Back Up the LoadMaster Configuration

The sections below contain instructions on how to back up the LoadMaster system configuration, SSL certificates, and any cipher sets in use.

#### Related Links

- [Back Up the System](#)
- [Back Up the Certificates](#)
- [Back Up Cipher Sets In Use](#)

## Back Up the System

### Back Up the System

Follow the steps below to create a backup file:

1. In the main menu of the LoadMaster Web User Interface (WUI), navigate to **System Configuration > System Administration > Backup/Restore**.

#### Create a Backup

---

Backup the LoadMaster **Create Backup File**

1. Click the **Create Backup File** button.

A download of the backup will start. The file name is set to **LMbackup** and the date and time. Select a location to save the backup file to – this is browser-dependent as some browsers will automatically save the file to a location that was already pre-set. The backup file will contain all of the LoadMaster base information such as system defaults and all information pertaining to each configured Virtual Service. If you rename the file, ensure to not change the file extension.

## Back Up the Certificates

### Back Up the Certificates

To back up certificates, follow the steps below:

1. In the main menu of the LoadMaster WUI, go to **Certificates & Security > Backup/Restore Certs.**

#### Certificate Backup

Backup all VIP and Intermediate Certificates

---

Passphrase	<input type="password" value="....."/>	<b>Create Backup File</b>
Retype Passphrase	<input type="password" value="....."/>	

1. Enter a **Passphrase** in the text boxes provided.

---

**Note:** The passphrase is very important and should be safeguarded. The backup file cannot be opened without the passphrase as it is encrypted.

---

1. Click the **Create Backup File** button.
2. The filename is automatically set with **CertBackup** and the date and time. Select the location to save the backup file to – this is browser-dependent as some browsers will automatically save the file to a location that was already pre-set. It is a good idea to save this file with the system backup. The file can be renamed but do not change the file extension.

---

**Note:** The private keys are backed up as part of the certificate backup. Even though this file is password protected – it should be stored securely as it contains private key material.

---

## Back Up Cipher Sets In Use

### Back Up Cipher Sets In Use

The built-in LoadMaster cipher sets may be automatically changed during a firmware upgrade. As a result, you may want to save a copy of the current cipher sets you have in use. The steps below provide instructions on how to do this for the **BestPractices** cipher set, as an example:

1. In the LoadMaster WUI, go to **Certificates & Security > Cipher Sets.**
2. Select **BestPractices** in the **Cipher Set** drop-down list.
3. In the **Save as** text box, enter a name for the cipher set to save, for example, **BestPractices-7.2.58.**

You can assign this cipher set to your Virtual Services as needed in the **SSL Properties** section of the Virtual Service modify screen.



# Updating the Software

## Updating the Software

---

**Note:** As the update process requires a reboot, we recommend that the software update is performed during a maintenance window.

---

To update the software, follow the steps below:

1. In the main menu of the LoadMaster WUI, navigate to **System Configuration > System Administration > Update Software**.

### Update LoadMaster Software

---

Software Update File:  7.1-Patch32...00-10G.bin

2. Click **Choose File** in the **Update LoadMaster Software** section and navigate to the software file that was downloaded from the Progress Kemp site.

---

**Note:** Do not install an ECS update image on a LoadMaster without the ECS add-on package already installed. Doing so invalidates your LoadMaster license.

---

3. Click **Update Machine**. The file is checked and validated.
4. Click **OK** to proceed and install the software after validation is complete. Once installed, the LoadMaster will need to be rebooted.
5. Click **Reboot**.
6. Click **Continue**.

## Please Enable Kemp Analytics

---

### Kemp Analytics

Help Kemp improve products and services by automatically sending anonymous diagnostic and usage data. None of the collected data identifies you personally. Data may include:

#### Performance

We sample network and appliance performance and use the aggregated data to provide indicators and guidance on how specific models and platforms are behaving.

#### Feature Usage

We gather statistics on feature usage to enable us to focus and prioritize enhancements on the features and capabilities that are most important to our customers.

For more information visit <https://kemp.ax/KempAnalytics>

The Kemp Analytics feature is currently disabled. Please click **Enable Kemp Analytics** to turn it on.

---

**Don't Enable Kemp Analytics**

**Enable Kemp Analytics**

If you are updating the software to version 7.2.49.1 or higher, a screen appears to enable Kemp Analytics. To enable this feature, click **Enable Kemp Analytics**. To proceed without enabling this feature, click **Don't Enable Kemp Analytics**.

For further details, refer to the following pages:

- [Call Home - Disclosure and Usage](#)
- [Kemp Analytics Disclosure and Usage](#)

---

# Restoring the Software

---

## Restoring the Software

When performing a software update, the LoadMaster automatically creates a restore point of the current system and, provided no changes are made, the restore point can be used. Therefore, when restoring to a previous version there are two options;

- Restore to the previous version – no changes made
- Restore to the previous version – changes made

Refer to the relevant section below for restore instructions.

### Related Links

- [Restore the Software – No Changes Made](#)
- [Restore the Software – Changes Made](#)
- [Restoring Certificates and Private Keys](#)

## Restore the Software – No Changes Made

### Restore the Software – No Changes Made

If there have been no further changes to the configuration since the software update, the software can be restored by following the steps below:

1. In the main menu of the LoadMaster WUI, go to **System Configuration > System Administration > Update Software**.

## Restore Previous version

---

Previous version: 7.2.50.0.18451.DEV.20200226-1739 **Restore Software**

2. Click the **Restore Software** button and click **OK** to confirm.
3. Reboot the LoadMaster.

After the reboot, the LoadMaster is restored to the time before the software update and it is fully operational, as it was at that time.

## Restore the Software – Changes Made

### Restore the Software – Changes Made

If changes have been made and you want to keep those changes, you will need to back up the system by following the steps in the [Back Up the System](#) section. Then, after restoring the software (steps in the [Restore the Software – No Changes Made](#) section), the backup can be restored by following the steps below:

1. In the main menu of the LoadMaster (WUI), navigate to **System Configuration > System Administration > Backup/Restore**.

### Restore Backup

---

Backup File	<b>Choose File</b>	No file chosen
LoadMaster Base Configuration	<input checked="" type="checkbox"/>	
VS Configuration	<input checked="" type="checkbox"/>	
Geo Configuration	<input checked="" type="checkbox"/>	
ESP SSO Configuration	<input checked="" type="checkbox"/>	
<b>Restore Configuration</b>		

2. Click the **Choose File** button.
3. Browse to and select the backup file.

---

**Note:** We recommend restoring all settings (check all boxes).

---

4. Click the **Restore Configuration** button.
5. Click **Reboot**.
6. Click **Continue**.


# Restoring Certificates and Private Keys

## Restoring Certificates and Private Keys

To restore certificates, follow the instructions below:

1. In the main menu of the LoadMaster WUI, navigate to **Certificates & Security > Backup/Restore Certs.**

### Restore Certificates



Backup File  No file chosen

Which Certificates

Passphrase

2. Click the **Choose File** button. Locate and select the certificate backup file.
3. In the drop-down list select **All VS and Intermediate Certs.**
4. Enter the passphrase assigned to the certificate backup file.
5. Click **Restore Certificates** button.

---

# References

---

## References

Unless otherwise specified, the following documents can be found at <https://docs.progress.com/>.

**Licensing, Feature Description**