



Deployment Guide MobileIron

8 January 2024

Copyright

Visit the following page online to see Progress Software Corporation's current Product Documentation Copyright Notice/Trademark Legend: [Product Documentation Copyright Notice & Trademarks | Progress](#)

Table of Contents

Chapter 1: Introduction. 4

 Document Purpose. 4

 Intended Audience. 5

Chapter 2: MobileIron Templates. 6

Chapter 3: Create MobileIron Virtual Services. 8

 Create a MobileIron Sentry Virtual Service. 8

 Create a MobileIron VSP Virtual Service. 9

Chapter 4: References. 11

Introduction

Introduction

MobileIron Sentry is a key component of the MobileIron Platform. Sentry is an in-line gateway which manages, encrypts, and secures traffic between a mobile device and back-end enterprise systems.

MobileIron Sentry interacts with a company's ActiveSync server, such as a Microsoft Exchange Server. The ActiveSync server allows employees to access email, contacts, calendar, tasks, and notes from their mobile devices. MobileIron Sentry, with input from the Virtual Smartphone Platform (VSP), protects the ActiveSync server from unauthorized access. MobileIron VSP provides end-to-end security and management for apps, documents, and devices. IT can now establish a virtual perimeter to secure business data without compromising the privacy of data, even on employee-owned smartphones and tablets.

A LoadMaster can be used to load balance the MobileIron workload.

Related Links

- [Document Purpose](#)
- [Intended Audience](#)

Document Purpose

Document Purpose

This document is intended to provide guidance on how to deploy MobileIron with a LoadMaster. The Kemp Support Team is available to provide solutions for scenarios not explicitly defined.

Intended Audience

Intended Audience

This document is intended to be used by anyone deploying MobileIron with a LoadMaster.

MobileIron Templates

MobileIron Templates


Kemp have developed templates containing our recommended settings for MobileIron. These templates can be installed on the LoadMaster and used when creating each of the Virtual Services. Using a template automatically populates the settings in the Virtual Services. This is quicker and easier than manually configuring each Virtual Service. If needed, changes can be made to any of the Virtual Service settings after using the template.

Released templates can be downloaded from the **Templates** section on the Kemp documentation page: <http://kemptechnologies.com/documentation/>.

Note: If you create another Virtual Service using the same template, ensure to change the Service Name to a unique name.

For more information and steps on how to import and use templates, refer to the [References](#).

For steps on how to manually add and configure each of the Virtual Services, refer to the [Create MobileIron Virtual Services](#) section.



Create MobileIron Virtual Services

Create MobileIron Virtual Services

Refer to the two sections below for step-by-step instructions on how to create and configure the MobileIron Virtual Services.

Related Links

- [Create a MobileIron Sentry Virtual Service](#)
- [Create a MobileIron VSP Virtual Service](#)

Create a MobileIron Sentry Virtual Service

Create a MobileIron Sentry Virtual Service

The following lists the steps involved and values required to set up a MobileIron Sentry Virtual Service:

1. In the main menu of the LoadMaster Web User Interface (WUI), go to **Virtual Services > Add New**.

Please Specify the Parameters for the Virtual Service.

Virtual Address	<input type="text" value="10.154.11.81"/>
Port	<input type="text" value="443"/>
Service Name (Optional)	<input type="text" value="MobileIron Sentry"/>
Protocol	<input type="text" value="tcp"/>

2. Enter a valid IP address in the **Virtual Address** text box.
3. Enter **443** in the **Port** text box.
4. Enter a recognizable **Service Name**, for example **MobileIron Sentry**.
5. Click **Add this Virtual Service**.
6. Configure the settings as recommended in the following table:

Section	Option	Value	Comment
Standard Options	Transparency	Disabled	
	Extra Ports	8443, 9090	Click Set Extra Ports .
	Persistence Mode	Source IP Address	
	Timeout	1 Hour	Click Set Idle Timeout .
	Scheduling Method	Weighted Response Time	
	Idle Connection Timeout	900	Click Set Idle Timeout .
Advanced Properties	Add a Port 80 Redirector VS	https://%h%s	Click the Add HTTP Redirector button.
Real Servers	Real Server Check Parameter	HTTPS Protocol	Click Set URL .
	URL	/mics	

Create a MobileIron VSP Virtual Service

Create a MobileIron VSP Virtual Service

The following lists the steps and values required to set up a MobileIron VSP Virtual Service:

1. In the main menu of the LoadMaster Web User Interface (WUI), go to **Virtual Services > Add New**.

Please Specify the Parameters for the Virtual Service.

Virtual Address	<input type="text" value="10.154.11.82"/>
Port	<input type="text" value="443"/>
Service Name (Optional)	<input type="text" value="MobileIron VSP"/>
Use Template	<input type="text" value="Select a Template"/>
Protocol	<input type="text" value="tcp"/>

2. Enter a valid IP address in the **Virtual Address** text box.
3. Enter **443** in the **Port** text box.
4. Enter a recognizable **Service Name**, for example **MobileIron VSP**.
5. Click **Add this Virtual Service**.
6. Configure the settings as recommended in the following table:

Section	Option	Value	Comment
Standard Options	Transparency	Disabled	
	Extra Ports	8080, 8443, 9090, 9997	Click Set Extra Ports .
	Persistence Mode	Source IP Address	
	Idle Connection Timeout	1 Hour	Click Set Idle Timeout .
	Scheduling Method	Fixed Weighting	
	Idle Connection Timeout	1800	Click Set Idle Timeout .
	Real Server Check Parameter	HTTPS Protocol	Click the Add HTTP Redirector button.
Real Servers	URL	/mics	Click Set URL .

References

References

Unless otherwise specified, the following documents can be found at <https://docs.progress.com>.

Virtual Services and Templates, Feature Description